

CP-KIT

Concrete Pour Kit is used when L-010 in-ground uplights or L-017 marker lights are to be installed in new concrete.

Kit includes:

Collar / Pipe assembly

Junction Box with Cover and Cordgrip

Junction Box Shelf

Foam Disc (to plug top opening during pour)

Fasteners

Fixtures may be installed less than 5 ft (1.5 m) from the inside walls of a pool, spa, or fountain when supplied by listed transformers or power supplies that comply with NEC 680.23(A)(2).

INSTALLATION

1. Dig hole at fixture location twelve inches deep. If pea gravel is used, hole must be deep enough so top of gravel is twelve inches below grade.
2. Locate Junction Box at center of fixture location and join to conduit (by others).
3. Slip Junction Box Shelf over top of Junction Box, stepped side up.
4. Place Pipe/Collar assembly on Shelf, making sure Pipe rests in Shelf step.
5. Verify top of Collar is even with top of concrete forms. Make adjustments to hole depth as needed.
6. Install Foam Disc into Collar to prevent debris and concrete from entering cavity. If necessary, Foam can be secured in place with included 1"-long screws. If Foam is lost or damaged, the opening can be covered with tape until concrete is poured.
7. Carefully backfill around Pipe. Do not dislodge Pipe from Shelf.

IMPORTANT: When running the supply wire, leave a loop at least 12" long in the Junction Box so the connections can be made outside the pipe when installing the fixture.



www.BeachsideLighting.com
808-405-6732

